

INSTRUCTION MANUAL

Super Mini Bluetooth Speaker



Version: V3.0

1. About Super Mini Bluetooth Speaker

This is possibly the world's smallest in size Bluetooth speaker with incredible clarity of sound and volume. Ease for carry and a great companion for travel. With Bluetooth 3.0 wireless technology, it enables you to connect between Smartphone, PC notebook, iPad, portable handheld devices within 10 meters. You can enjoy all your music anywhere with your friends or use it as an external speaker for conference meeting. This mini speaker uses a new generation of amplifiers and you will be surprise by the incredible sound from such a small device!

2. Getting to Know Your Bluetooth Speaker phone

PRODUCT ILLUSTRATION

3. Getting Started

To use the Bluetooth speaker, please follow these simple steps:

- (a) Prior to using the speaker, it is recommendable to charge the battery fully for the first time.
- (b) Use the micro USB cable to connect the speaker to any computer with USB port. Charging time is approx 3 hours. After completion of charge, please remove the cable from speaker.
- (c) Make sure the speaker and your Bluetooth-enabled device such as your smart phone or tablet no more than 1 meter away for the initial pairing process.
- (d) Once paired, ensure your speaker and your Smartphone is always within a 10-meter Bluetooth sensing distance. (Obstruction could cause shorter sensing distance.)

Note:

- Charge time: Normal full charge time is around 3 hrs.
- Charge indication: When charge is in process, the charging indicator light will be red. When the charge is completed, the charging indicator will turn off.
- Low battery indication: You will hear a voice alert of "Low battery, please recharge" It's recommended to charge the speaker immediately to prolong durability of battery and standby time. When the speaker has a low battery status, if the battery is not charged within a certain time, the speaker will switch itself off.

Warning:

Do not charge the speaker with other unsuitable AC/DC power adaptors, it may cause damage to the speaker. The speaker must be charged properly by USB ports or by a AC/DC adaptor with Input: AC100-240V, 50-60Hz Output: DC 5V 500mA

To keep the battery in good condition, charge the speaker at least once every 3 months.

4. Turning the speaker On/Off

Turning On: Speaker is under off mode:

Press and hold the PLAY ► || button for 4 seconds, you will hear a voice alert saying "Bluetooth". The Standby indicator light will flash in blue.

Turning Off: Speaker is under standby mode or running mode:

Press and hold the PLAY ► || button over 4 seconds, you will hear a voice alert saying "Power off". All standby indicator lights will be turned off.

5. Pairing

Prior to using the speaker for the first time, you must pair it with a Bluetooth-enabled device eg. your Smartphone, iPad, iPhone etc.

The following steps describe pairing process for a typical Bluetooth-enabled device.

- (a) Ensure the speaker is switched OFF.
- (b) Place the speaker and your Smartphone not more than 1 meter apart.
- (c) Switch on the speaker by press and hold the PLAY ► || button for 4 seconds.
- (d) Press and hold the " " button to activate the pairing mode; the standby indicator will **flash in red and blue alternatively**. It's now ready for pairing.
- (e) Activate your Smartphone's Bluetooth function, the Smartphone will search for accessible Bluetooth devices. (For details, please refer to the user guide of the Smartphone)
- (f) Select "**SSIS_music**" from the searching list and press "OK" to pair the speaker
- (g) Some Bluetooth smart phones or devices will ask for a **passkey**, please enter "0000" and press "OK" to pair the speaker.
- (h) When pairing is completed, you will hear a voice alert "Connected". Now the speaker is ready for use and in standby mode; this is indicated by a flashing blue light every 3 seconds.
- (i) You should now be able to use the wireless speaker to listen the music. Please place your Bluetooth device within 10m of the speaker. (Obstructions could cause shorter sensing distance.)

NOTE:

- Whenever Bluetooth connection/link is removed, for example: power off on speakerphone/mobile handset or out of 10 meter sensing distance, please activate connection/link as suggested.

6. Operate the Speaker

Once pairing is completed and battery is fully charged, you may access the following functions. Some of the below-mentioned function is only accessible for Smartphones that support with Hands-Free Profile.

(a) Play / Pause the music:

Short press the PLAY ► || button to pause and re-play music in your Smartphone or you can do it via your Smartphone in the normal way.

(b) Adjusting the Volume:

During speaker playing or conversation is in progress, press and hold the reduce volume "◀◀" button and increase volume "▶▶" button repeatedly until you reach the desired volume level.

NOTE:

Volume level of your Smartphone is control by the Smartphone, volume control button of speaker will not control your Smartphone volume level.

(c) Play Next / Previous Song:

Quick press the "⏮" button to play previous song, and press "⏭" button to play next song

(d) Answering a Call:

To answer a call, wait for the speakerphone to ring with a voice alert "Calling", then short press the " " button to accept the call or answer the call via your Smartphone in the normal way. **If iPhone models are connected to this Bluetooth speaker, when there is an incoming call, both the speaker and iphone will play the incoming ringtone; for other Smartphone models, only the Smartphone will play the incoming ringtone.**

NOTE: Please try to keep 30-50cm distance from speaker when answering a call.

(e) Ending a Call:

A short press of the " " button will end your call or you can end the call via your Smartphone in the normal way.

(f) Reject a call

Please reject the call via your Smartphone in the normal way.

(g) Last Number Re-Dialing:

Under standby mode, short press " " button twice for last number redial.

(h) Mute & Un-mute:

Please mute the call via your Smartphone in the normal way.

7. Disconnection between Speaker and your Smartphone:

Please follow the simple steps to disconnect the speaker with the pre-paired Smartphone

- (a) **Long press** the " " button for around **2 seconds**
- (b) Power off the speaker by **4 seconds** press the **PLAY ▶ ||**
- (c) Or simply unpair/disconnect the speaker via your Bluetooth options on your smartphone.

8. Connect the speaker with 3.5mm audio cable

You can also connect to portable speaker with a 3.5mm audio cable to hear your music if you do not want to use Bluetooth. **Keep the speaker in OFF mode first, then connect the cable to the line-out socket of your audio source, and plug the 3.5mm cable back into the speaker.**

NOTE:

Please note that all control buttons on the speaker cannot control the Smartphone when connected with the audio cable

9. Safety Cautions & Maintenance

- (a) Do not charge the speaker with other unsuitable AC/DC power adaptor, it may cause damage to the speaker. The speaker must be charged properly by USB ports or by a AC/DC adaptor with Input: AC100-240V,50-60Hz Output: DC 5V 500mA
- (b) Stop using the speaker and switch on the speaker immediately, if you find any overheating situation, strange noise and strange working performance during use
- (c) Do not drop the speaker on floor / ground, as the plastic housing of speaker could be damaged and broken
- (d) Do not expose the speaker to liquid, moisture or humidity, as it is not waterproof.
- (e) Do not use abrasive cleaning solvents to clean the speaker.
- (f) Do not place the speaker in high temperature, as it will result in an explosion.
- (g) Do not expose the speaker to contact with sharp objects as this will cause scratching and damage.
- (h) Do not stick anything inside the speaker or front panel as this may damage internal components.
- (i) Do not attempt to disassemble the speaker, as it does not contain serviceable components.
- (j) If you do not use the speaker for long periods, be sure to store it in a dry place, free from extreme temperature, humidity and dust.

SAFETY REMINDER:

- (a) Check local laws regarding use of a mobile headset and speakerphone while driving. If you use the hands free speakerphone with this speaker while driving, ensure your attention and focus remains on your responsibility of driving safety.
- (b) Never allow children to play with the speaker. Small parts may be a choking hazard.
- (c) Observe all signs that require an electrical device or RF radio product to be switched off in the designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
- (d) Turn off your speaker and Bluetooth signal prior to boarding an aircraft. Do not use your speaker in an aircraft.
- (e) Never mount or store your speaker over any air bag deployment area. Serious injury may be resulted when an air bag deploys.

10. Trouble Shooting

If you are unable to connect your speaker and your Smartphone, please try the following:

- (a) Ensure the speaker is paired with your Smartphone.
- (b) Ensure your Smartphone's Bluetooth feature is activated. Please refer to your Smartphone user guide for specific instruction.
- (c) Ensure the speaker is within a maximum of 10 meters of your mobile headset(s) and there are no obstructions, such as thick solid wall or other electronic devices in between as it may cause shorter or interference transmission.
- (d) If all the above steps do not resolve your problem, please turn off the speaker for a while. The Bluetooth speaker is compliance with and adopts the Bluetooth Specification V3.0. However, interoperability between the device and other Bluetooth-enable products is not guaranteed because it depends on compatibility. For more information on the compatibility between the device with other Bluetooth-enabled products, please check with the manufacturer/importer.
- (e) If you are not able to link up with Bluetooth, please check whether any other devices are keep connecting with the Bluetooth speaker, or the speaker did not link up the audio and media channel of the devices after pairing.

11. Product Specifications

Signal / Noise Ratio	: > 80dB
Driver	: 4oHm 3 Watt
Rating Power	: 2W
Line in	: 3.5mm Dia.
Rechargeable Li-ion Battery	: 3.7V DC, 300mAh
Power Input	: Micro USB (5V/500mA)
AC/DC Charger	: DC 5V, 500 mA
Normal Charge Time	: 3 hrs.(approx.)
Microphone talking range	: within 30-100cm
Talk Time	: 3 hrs.
Standby Time	: 12 hrs.
Bluetooth Specifications	: Version 3.0, Class 2, 10 Meters
Bluetooth Profile Supported	: Headset & Hands-Free Profiles
Operating Frequency Band	: 2.402 to 2.480GHz
Dimension(L/M/S)	: W32 x H38 mm
Weight	: 42 grams

12. Voice Alert

Switch on	"Bluetooth"
Pairing mode	"Pairing"
Devices connected	"Connected"
Pairing Disconnected	"Disconnected"
Receive income call	"Calling"

Already Max Volume

"Maximum Volume"

Already Min Volume

"Minimum Volume"

Re-dial Last call

"Calling"

Low battery

"Low battery, please charge"

Power off

"Power off"